


STEP 1 - Loosen wing nuts and Swing side legs out.



STEP 2 - Swing middle leg out.



STEP 3 - Extend legs and tighten wing nuts.



STEP 4 - Open locks.



STEP 5 - Open box to desired position and tighten side wing nuts.



STEP 6 - Slide canvas tray down track and tighten knob at desired position. Then slide top canvas holder down track to desired position and tighten thumb screw.

